



How to measure for Perfect Fit blinds

STEP 1 MEASURING THE WIDTH:

Using a steel tape measure, measure from rubber seal to rubber seal. This is the actual glass you can see. You need to do this across the top, middle and bottom of the window.

STEP 2 MEASURING THE DROP:

As above measure the actual glass you can see. You need to do this across the left, middle and right of the window.

STEP 3 TAKING YOUR MEASUREMENTS:

Always write down your measurements as 'width and then drop' use the smallest measurement from your 3 measurements you have taken. This will ensure a perfect fit.

STEP 4 HANDLES AND VENTS:

If you have a handle or vent on your window you need to make certain that there is enough room for the Perfect Fit Blind to fit nicely. Using a steel tape measure and a square object, measure from the base plate of the handle/vent to the rubber seal (where the glass starts). You need to keep the tape parallel to the glass for an accurate measurement. If you have 22mm or more then you are fine. If you don't have this clearance you may still have perfect fit blinds but you will need to call us for advice.

STEP 5 BEADING DEPTH:

In order for us to supply the correct bracket and punch the frames correctly we need the depth of the window beading. To do this simply put a straight edge across the corner of your window and then measure down to the glass. This measurement needs to be taken in millimetres and can be between 10mm and 34mm.



Questions?



just call us

Helpful Guides

phone Local rate: 0845 652 1963